



SUNSHADE

Here are a few examples of a completed sunshade.



Push the wire into the groove and rotate the two rubber prongs upward. You may have to pull back the rubber on the prongs.



Slide the rubber back up the wire until it fits into the inlays.